

ANALYTE DETECTION IN LIQUIDS WITH CARBON NANOTUBE FIELD EFFECT TRANSMISSION DEVICES

ABSTRACT OF THE DISCLOSURE

Field-effect transistor (FET) devices with carbon nanotubes as the conducting
5 channel detect chemicals in liquids are described. Chemical detection occurs primarily
through analysis of conduction (I) as a function of the applied gate voltage (V_g). The
conductivity of liquids is an important variable in the analysis of measurements of the
device performance. In high-conducting liquids, screening and liquid conductance
dominate in the device measurements; in low-conductive liquids (e.g., cyclohexane), the
10 changes in the NTFET device performance upon exposure to different chemicals are
similar to those found for the performance of the device in a gaseous environment. The
influence of aromatic compounds on the device electronics can be correlated with their
relative ability to donate or withdraw electrons from the carbon nanotube. A shift in the
threshold of I - V_g was found to be linear with Hammett sigma values (σ_p) for mono-
15 substituted benzene compounds.